





## UV Analyser UVA 17 HW e

- for process applications (e.g. **NO,N02**, NH3 after **DENOX**)
- compact analysis system for wall mounting based on UVA 17 HW analyser
- air-conditioned, incl. membrane air dryer for compressed air treatment and power supply
- short response times due to short sampling paths
- heated measuring cell (max.200 °C)
- O2 measurement using zirconium dioxide sensor
- ejector-based measuring gas conveyance
- no gas conditioning, no gas cooler necessary
- rather low demand for maintenance & wear/spear parts
- touch display, app-based menu & remote access



