









































The DAS has a provision for making up for missed purge activations. Suppose that the reservoir is empty for some time or the DAS is not running but the meter is still in the process and one or more purge activations are missed. When the DAS is able (reservoir filled or DAS powered) it will attempt to make up for missed purge activations. For example if the DAS is configured to make 2 strokes every 6 hours and the reservoir was empty for 24 hours, then the DAS will attempt to make 8 strokes. But what if the reservoir was empty for 2 weeks? The DAS would attempt to make 112 strokes. This is obviously more than necessary. There is a configurable maximum strokes per activation that can be used to limit this behavior. Example: A maximum of 50 strokes to purge the capillaries.

## 2.13 MPFM Electrical

The MPFM is adapted to meet the requirements for use in hazardous areas. The applicable design is determined by the customer's request. See APPENDIX A for customer drawings and see APPENDIX C for the electrical drawings and specifications of your MPFM unit.